


## WRENCH TO OPEN VALVE OF CP4 PUMPS

### AC0530-CP4

Wrench to disassemble and assemble valve of CP4 pumps  
Valve similar: 1.467.C45.003



### AC0539-CP4

Wrench to disassemble and assemble valves with 2 holes on CP4 pumps similar  
to 0.445.011.542



### AC0547-CP4

Wrench to disassemble and assemble valves on CP4 pumps  
similar to 0.445.010.793 – 0.445.011.508 – 0.445.011.532 – 0.445.011 551  
Valve similar: 1.467.C45.015

